MAINCOMS

QUICK REFERENCE GUIDE

Yealink T88W

For Yeastar P-Series

The T88W is a desk phone with a 7-inch tilting touchscreen running Yealink's Android-based software, built-in Bluetooth and Wi-Fi, and physical keys for hold, transfer, redial, message, headset and mute. The T88W Pro adds a cordless Bluetooth handset. It arrives set up for your system: plug it into a Power over Ethernet network point, or use the Yealink power adapter, and allow a few minutes for it to start.

Getting to know your phone



- **Touchscreen**
  Tap to dial, choose contacts and use the on-screen keys, including line and colleague keys.
- **Power light**
  Flashes when the phone rings or a voicemail is waiting.
- **Headset and Mute**
  HEADSET switches to a headset. **MUTE** turns your microphone off and on.
- **Message**
  MESSAGE dials your voicemail.
- **Call keys**
  HOLD holds or resumes a call. **TRANSFER** starts a transfer. **REDIAL** shows numbers you have dialled.
- **Speakerphone and volume**
  Hands-free calls, and the volume of the call or ringer.
- **Keypad**
  Enter numbers, letters and symbols.

Key lights

Light	Meaning
HEADSET or Speakerphone lit	That mode is in use
MUTE lit	Your microphone is off
On-screen line keys	Show call and colleague status as icons
Power light flashing slowly	Voicemail or message waiting

Good to know. Your line keys and soft keys are set up for your business, so the labels on your phone may differ slightly from this guide. If a key is not where you expect, call us and we will check it for you.

Yealink T88W

For Yeastar P-Series

Everyday tasks

Make a call

1. Lift the handset, or press **Speakerphone** or **HEADSET**.
2. Dial the number on the screen keypad.
3. Tap **Send**, or wait a few seconds for the call to connect.

Answer a call

Lift the handset, press **Speakerphone** or **HEADSET**, or tap **Answer**. If you are already on a call, tap **Answer** and your first call is put on hold.

Hold and resume

Press **HOLD** to put a caller on hold. Press **HOLD** again, or tap **Resume**, to return to them.

Mute

Press **MUTE**. The key lights while your microphone is off. Press it again to unmute.

Transfer without speaking first

1. During the call, press **TRANSFER**.
2. Dial the number or extension.
3. Press **TRANSFER** again, or tap **B Transfer**. The call goes straight through.

Transfer after speaking first

1. During the call, press **TRANSFER**; the caller is held.
2. Dial the number and tap **Send**.
3. When your colleague answers, introduce the call, then press **TRANSFER**. To go back to the caller instead, tap **Cancel**.

Three-way conference

1. During a call, tap **Conference**; the first caller is held.
2. Dial the second person and tap **Send**.
3. When they answer, tap **Conference** again to join everyone. Hanging up ends the call for all three.

Redial

Press **REDIAL** to see the numbers you have dialled and choose one, or press **REDIAL** twice to call the most recent number.

Call history and directory

Open the History app to see missed, received and dialled calls, or Contacts for your directory. Tap an entry to call it.

Do not disturb

Open the Call, Contacts or History app, tap the settings icon, then turn on DND. Callers go to voicemail until you turn it off.

Forward your calls

1. Open the Call, Contacts or History app and tap the settings icon.
2. Tap Call Forward and choose Always, Busy or No Answer.
3. Turn it on, enter the number and tap **Save**. Turn it off the same way.

Voicemail

Press the **MESSAGE** key, or dial ***2**. The power light flashes slowly when you have a new message.

Feature codes on Yeastar P-Series

***2**	Listen to your voicemail	***12 + ext**	Leave a voicemail for a colleague
***3 + ext**	Attended transfer during a call	***03 + ext**	Blind transfer during a call
***31 + number / *031**	Forward all calls on / off	***93 / *91**	Do not disturb / available
***4**	Pick up a call ringing in your group	***04 + ext**	Pick up a call ringing on a colleague's phone
***5 / 6xxx**	Park a call / retrieve it from slot 6xxx	***1**	Start or pause call recording, if enabled

Standard Yeastar codes. If your system has been customised, yours may differ.